

Perfect Pergolas Ltd, PO Box 283
Cirencester, Glos GL7 9EY
t: 0844 800 4703

e: info@perfectpergolas.co.uk **w:** www.perfectpergolas.co.uk

MOD 4 – ASSEMBLY INSTRUCTIONS Parts List

- A 2 x Main Beams, scarfed both ends, pre-drilled –2.7mtrs Length
- **B** 4 x Cross Rafter, scarfed both ends 2.7mtrs Length
- **C** 4 x Posts, Notched and Pre-Drilled 2.4mtrs Length
- **D** 8 x Struts Pre-Drilled
- **E** 16 x Angle Brackets
- **F** 4 x Coach Bolt Sets (bolt, washer and nut)
- **G** 96 x Wood Screws (for angle brackets) 25mm x No.8
- **H** 16 x Wood Screws (for struts) 50mm x No.8
- 4 x Post Fixings (Spike, Concrete-In or Bolt-Down incl. ankerbolts)



Fig 2. - Marking Out Post Positions

With a measure make sure lines A and B are the same length.

* N.B.: Please take measurement dimensions to CENTRE of post fixings.







Fig 3. - Fitting of Post Supports







Option 2:Bolt Down System












Fig 7. - Finish

As some of the screws & bolts may have become loose during assembly, it is important to re-check that they are tight and ensure they are securely fastened.